





30mm ϕ SELECTOR SWITCHES, ILLUMINATED SELECTOR

LUSS 30-1O/C,1-2 SPRING RETURN
LUSS 30-2/O,1-0-2 SPRING RETURN




KEY SELECTOR SWITCH AKSS 30-1/O(N/O),
30mm ϕ
AKSS 30-1/C(N/C)
AKSS 30-1O/C (N/O+N/C), 2Position
AKSS 30-2/O (2N/O), 3Position




NISS 30-1O/C,1-2
NISS 30-2/O,1-0-2

ILLUMINATED




KEY SELECTOR SWITCH AKSS 22-1/O(N/O),
22mm ϕ
AKSS 22-1/C(N/C)
AKSS 22-1O/C (N/O+N/C), 2Position
AKSS 22-2/O (2N/O), 3Position




NUSS 30-1O/C,1-2 SPRING RETURN
NUSS 30-2/O,1-0-2 SPRING RETURN

ILLUMINATED




RAIN PROOF PUSH BUTTON RPB 30-1/O
30mm ϕ
RPB 30-1/C
RPB 30-1O/C




TISS 30-1O/C,1-2
TISS 302/O,1-0-2

ILLUMINATED



RAIN PROOF PUSH BUTTON RPB 22-1/O
22mm ϕ
RPB 22-1/C
RPB 22-1O/C



TUSS 30-1O/C,1-2
TUSS 30-2/O,1-0-2

SPRING RETURN
SPRING RETURN
ILLUMINATED

