


1 pushbutton "START"		AP/ST-1
1 pushbutton "STOP"		AP/ST-2
1 mushroom head pushbutton.		AP/ST-3
1 Latching mushroom head pushbutton. "STOP"		AP/ST-4
1 illuminated pushbutton with neon lamp "STOP"		AP/ST-5
2 pushbutton "START" "STOP"		AP/ST-6
2 illuminated pushbutton with neon lamp "START" "STOP"		AP/ST-7

3 pushbuttons "FORWARD" "REVERSE" "STOP"		AP/ST-8
3 pushbuttons "UP" "DOWN" "STOP"		AP/ST-9
1 red pilot light with neon lamp 2 Pushbuttons "START" "STOP"		AP/ST-10
3 illuminated push button with neon lamp		AP/ST-11



	A	B
1 button	78	67
2 button	111	89
3 button	151	130
4 button	185	150
5 button	222	184