

MULTI-STEP SWITCHES WITHOUT "OFF" 20A

Code No	Function	Stage	Escutch plate	Connection diagram	
C114	1 pole 3 step	2			
C115	2 pole 3 step	3			
C116	3 pole 3 step	5			
C117	4 pole 3 step	6			
C120	1 pole 4 step	2			
C121	2 pole 4 step	4			
C122	3 pole 4 step	6			
C126	1 pole 5 step	3			
C127	2 pole 5 step	5			
C128	3 pole 5 step	8			
C130	1 pole 6 step	3			
C131	2 pole 6 step	6			
C134	1 pole 7 step	4			
C135	2 pole 7 step	7			
C137	1 pole 8 step	4			
C138	2 pole 8 step	8			
C139	3 pole 8 step	12			
C140	1 pole 9 step	5			
C141	1 pole 10 step	5			
C142	1 pole 11 step	6			
C143	1 pole 12 step	6			
C144	1 pole 2 step	1			
C145	2 pole 2 step	2			
C146	3 pole 2 step	3			
C147	4 pole 2 step	4			
C148	5 pole 2 step	5			

