

MULTI STEPSWITCHES WITH "OFF" 20A

Code No.	Function.	Stage	Eschtch plate	connection diagram
C149	1 pole 3 step	2		
C150	2 pole 3 step	3		
C151	3 pole 3 step	5		
C152	4 pole 3 step	6		
C153	5 pole 3 step	8		
C154	1 pole 4 step	2		
C155	2 pole 4 step	4		
C156	3 pole 4 step	6		
C157	4 Pole 4 Step	8		
C158	1 pole 5 step	3		
C159	2 pole 5 step	5		
C160	3 pole 5 step	8		
C161	1 pole 6 step	4		
C162	2 pole 6 step	7		
C163	3 pole 6 step	11		
C164	1 pole 7 step	4		
C165	2 pole 7 step	8		
C166	1 pole 8 step	5		
C167	1 pole 9 step	5		
C168	1 pole 10 step	6		
C169	1 pole 11 step	6		



MOTOR REVERSING SWITCHES 20A

C170	2 pole	3			
C171	3 pole	4			

MOTOR REVERSING SWITCHES 20A

C172	2 speed	3			
C173	4 pole - 8 pole Speed control and Reversing Control	7			