

CAM SWITCH



VOLTMETER WITCHES

Code No.	Stage	Escutch Plate	connection diagram	
C174 3 phase 3 wire	3	 P53 P54		
C175 3 phase 4 wire	4	 P55 P56		
C176 3 phase 4 wire	4	 P57 P58		

AMMETER SWITCHES

Code No.	Stage	Escutch Plate	connection diagram	
C177 3 phase 3 wire 2 current transformer	3	 P59 P60		
C178 3 phase 4 wire 3 current transformer	4	 P61 P62		
C179 3 phase 4 wire 3 current transformer	4	 P63		