

# CAM SWITCHES 20A



## ON-OFF switches 45 °,60 °,90 °, switching 20A

Code No	Function	Stage	Escutch plate	Connecting Diagram
A201	1 Pole	1	 10	Stage 1 Stage 2 
A201A	2 Pole	1		
A202	3 Pole	2		
A202A	4 Pole	2	 11	Stage 3 Stage 4 
A203	5 Pole	3		
A203A	6 Pole	3	 12	
A204	7 Pole	4		
A204A	8 Pole	4	 13	
A205	9 Pole	5		
A205A	10 Pole	5		
A206	11 Pole	6		
A206A	12 Pole	6		

## Change over switches without OFF 90 °,60 °,45 °,30 °, switching 20A

A207	1 Pole	1	 16	 17		
A208	2 Pole	2				
A209	3 Pole	3	 18	 19		
A210	4 Pole	4				
A211	5 Pole	5				
A212	6 Pole	6				

## Change over switches without OFF with electrically isolated contacts 20A

A213	1 Pole	1	 16	 18		
A214	2 Pole	2				
A215	3 Pole	3	 19	 18		
A216	4 Pole	4				

## Change over switches with center OFF 60 °,45 °,90 ° switching 20A

A217	1 Pole	1	 20	 21		
A218	2 Pole	2				
A219	3 Pole	3	 22	 21		
A220	4 Pole	4				
A221	1 Pole	1				
A222	2 Pole	2				
A223	3 Pole	3				
A224	4 Pole	4				