

CAM SWITCHES 20A



ON-OFF switches 45 °,60 °,90 °, switching 20A

Code No	Function	Stage	Escutch plate	Connecting Diagram
A201	1 Pole	1		Stage 1 Stage 2
A201A	2 Pole	1		
A202	3 Pole	2		Stage 3 Stage 4
A202A	4 Pole	2		
A203	5 Pole	3		
A203A	6 Pole	3		
A204	7 Pole	4		
A204A	8 Pole	4		
A205	9 Pole	5		
A205A	10 Pole	5		
A206	11 Pole	6		
A206A	12 Pole	6		

Change over switches without OFF 90 °,60 °,45 °,30 °, switching 20A

A207	1 Pole	1			
A208	2 Pole	2			
A209	3 Pole	3			
A210	4 Pole	4			
A211	5 Pole	5			
A212	6 Pole	6			

Change over switches without OFF with electrically isolated contacts 20A

A213	1 Pole	1			
A214	2 Pole	2			
A215	3 Pole	3			
A216	4 Pole	4			

Change over switches with center OFF 60 °,45 °,90 ° switching 20A

A217	1 Pole	1			
A218	2 Pole	2			
A219	3 Pole	3			
A220	4 Pole	4			
A221	1 Pole	1			
A222	2 Pole	2			
A223	3 Pole	3			
A224	4 Pole	4			